


SM-T-3265

Tilting TV Wall Mount support mural inclinable pour écran plat

INSTRUCTION MANUAL MANUEL D'INSTRUCTIONS



www.syncproducts.com

DISCLAIMER - WARNING INFORMATION

AVIS DE NON-RESPONSABILITÉ - INFORMATIONS D'AVERTISSEMENT

Disclaimer -- SYNCPRODUCTS has extended every effort to ensure to accuracy and completeness of this manual. However, SYNCPRODUCTS does not claim that the information covers all installation and or operational variables. The information contained in this document is subject to change without notice or obligation of any kind. Regarding the information contained herein, SYNCPRODUCTS makes no representation of warranty, expressed or implied, and assumes no responsibility for accuracy, sufficiency, or completeness of the information contained in this document.

WARNING: FAILURE TO READ, THOROUGHLY UNDERSTAND, AND FOLLOW ALL INSTRUCTIONS CAN RESULT IN SERIOUS PERSONAL INJURY, DAMAGE TO PERSONAL PROPERTY, OR VOIDING OF FACTORY WARRANTY!

Do not attempt to install or assemble this product if the product or hardware is damaged or missing. The included hardware is designed for use on vertical walls constructed of wood studs.

Mounting Surfaces - These units are intended for use on 2 by 4 in. (or larger) wood stud wall with 5/8 in. (or thinner) ceiling, plasterboard, or similar material. The included hardware is not designed for use with metal studs or cinderblock walls. If you're uncertain about the construction of your wall, then please consult a qualified contractor or installer for assistance. For a safe installation, the wall you are mounting to must support 4 times the weight of the total load. If not, then the surface must be reinforced to meet this standard. The installer is responsible for verifying that the wall structure and hardware used in any installation method will safely support the total load.

FRANÇAIS


Avis de non-responsabilité -- SYNCPRODUCTS a déployé tous ses efforts pour assurer l'exactitude et l'exhaustivité de ce manuel. Cependant, SYNCPRODUCTS ne prétend pas que les informations couvrent toutes les variables d'installation et/ou de fonctionnement. Les informations contenues dans ce document sont susceptibles d'être modifiées sans préavis ni obligation d'aucune sorte. En ce qui concerne les informations contenues dans le présent document, SYNCPRODUCTS ne fait aucune représentation de garantie, expresse ou implicite, et n'assume aucune responsabilité quant à l'exactitude, la suffisance ou l'exhaustivité des informations contenues dans ce document.

AVERTISSEMENT : NE PAS LIRE, BIEN COMPRENDRE ET SUIVRE TOUTES LES INSTRUCTIONS PEUT ENTRAÎNER DES BLESSURES GRAVES, DES DOMMAGES MATÉRIELS OU L'ANNULATION DE LA GARANTIE D'USINE !

N'essayez pas d'installer ou d'assembler ce produit si le produit ou le matériel est endommagé ou manquant. Le matériel inclus est conçu pour être utilisé sur des murs verticaux constitués de montants en bois ou en béton solides. Un mur à ossature de bois est défini comme étant constitué d'un minimum de 2 x 4 montants de bois (2 po de large sur 4 po de profondeur) avec une cloison sèche d'un maximum de 5/8 po. Le matériel inclus n'est pas conçu pour être utilisé avec des montants métalliques ou des murs en parpaings. Si avez des doutes au sujet de la structure de votre mur, veuillez consulter un entrepreneur ou un installateur qualifié pour obtenir de l'aide. Pour assurer la sécurité de l'installation, le mur sur lequel vous effectuez l'installation doit supporter 4 fois le poids de la charge totale. Si ce n'est pas le cas, la surface doit être renforcée pour répondre à cette norme. L'installateur a la responsabilité de vérifier que la structure du mur et le matériel utilisé lors de l'installation supporteront en toute sécurité la charge totale.

TOOLS NEEDED


Outils Requis




SYMBOLS SYMBOLES



HARDWARE PRODUCT NUMBERS




PRODUCT COMPONENT PARTS



STEP 1A - FLAT BACK FLAT PANEL (VERTICAL RAILS)

Connect Vertical Rails to flat panel


Connectez l'adaptateur au moniteur



STEP 1B - CURVED BACK FLAT PANEL (VERTICAL RAILS)



Connect Vertical Rails to flat panel

Connectez l'adaptateur au moniteur



STEP 1- USE M8 STEEL WASHER IF THE PHILLIPS SCREWS FROM THE MONITOR KIT ARE TOO LONG




Diagrams show two options for using additional washers if hardware screws are too long to properly tighten into back of TV.



STEP 2- WOOD STUD INSTALLATION (CONCRETE INSTALLATION SKIP TO STEP 3)

Find stud and mark edge and center locations

Repérez l'emplacement d'une poutre, puis marquez l'emplacement des bords et du centre de cette poutre.




STEP 2A & 2B- LOCATE WOOD STUDS AND DRILL PILOT HOLES


Drill pilot hole

Percez le trou de guidage

Mark center of wood using stud finder and pencil, use wall plate to level and mark pilot holes.





Drill 4 pilot holes



STEP 2C- MOUNT WALL PLATE TO WALL

Mount wall plate
Montez la plaque murale

16" STUD (Medium Tilt Mount)
16" or 24" STUD (Large Tilt Mount)



STEP 3 – SOLID CONCRETE INSTALLATION

Use wall plate to mark mounting locations/ drill pilot holes

Utilisez la plaque murale pour marquer l'emplacement de montage

Level

Solid Concrete

Drill Bit

DRILL BIT NOT INCLUDED

3/8"

9.5-10 mm

(3/8")

(2 3/4") 70mm

Drill Pilot Hole


STEP 3A & 3B - POSITION WALL PLATE, MARK, & DRILL PILOT HOLES

Position wall plate to desired location, level, and mark pilot locations with pencil.



Drill 4 pilot holes

STEP 3C- SOLID CONCRETE INSTALLATION.

Mount wall plate
Montez la plaque murale




Insert wall Anchors gently into concrete wall with hammer if necessary




STEP 4A- ATTACH PANEL TO WALL PLATE

Hang vertical rails with monitor attached

Accrochez avec le moniteur installé.





STEP 4B- ADJUST THE SCREWS ON THE VERTICALS TO LEVEL THE FLAT PANEL



STEP 4C- ADDITIONAL SECURITY FEATURE (OPTIONAL)

Option
Option




Vertical Rails have 7mm hole located at the bottom for placement of pad lock for additional (theft) security (pad lock not included)

STEP 4D- ADDITIONAL FEATURE (OPTIONAL)

Manager the over length for the straps

**Attach pendant
to wall plate
with magnet.**



The length of the straps can be adjust if necessary

